Goldtouch

KB-X231-TM
USER MANUAL
Trident Standard Keyboard

CONGRATULATIONS ON YOUR PURCHASE

Please read this user manual before using the unit and keep this manual in a safe place for future reference.

Copyright

Trademarks

Goldtouch, the Goldtouch logo and Productivity through Prevention® are registered trademarks of Key Ovation, LLC. All other trademarks are copyright of their respective owners. All rights reserved.

Installation

1. Choose your preferred connection type: USB Wired, 2.4 Ghz Wireless with Dongle, or Bluetooth.

2. Follow the appropriate pairing instructions on the "Pair the Keyboard to Device" section.

FEATURES DESCRIPTION

- Model name: Trident Standard Keyboard

- Solution: USB + 2.4GHZ + 2 Channel Bluetooth keyboard, rechargeable

- Layout: US Layout

- Battery: 300mAh

Windows/Mac systems default to function shortcut keys

Mac systems default to function keys, while Windows systems default to F1-F12 keys.
Windows FN + Multimedia Key to engage function.
Mac no need for FN + Multimedia Keys. Mac System default is to engage function keys.

FN+Mulitmedia key	Window	Mulitmedia key	MAC
FN + F1	Brightness -	F1	Brightness -
FN + F2	Brightness+	F2	Brightness+
FN + F3	Multitasking window	F3	Multitasking window
FN + F4	Search	F4	Search
FN + F5	Microphone (Long press 0.5 sec)	F5	Microphone (Long press 0.5 sec)
FN + F6	Sleep	F6	Sleep
FN + F7	Previous	F7	Previous
FN + F8	Play/Pause	F8	Play/Pause
FN + F9	Next	F9	Next
FN + F10	Mute	F10	Mute
FN + F11	Volume-	F11	Volume-
FN + F12	Volume+	F12	Volume+
FN + 🔒	Screen Lock	🔒	Screen Lock
FN + Backspace	Delete	FN + Backspace	Delete
FN + PrtSc	Print screen	FN + PrtSc	Print screen

Remarks:
- When turning on the keyboard , note the connection status indicators for the first 4-5 seconds , if not successfully connected, the keyboard will enter pairing mode of your last selected choice.

- If Keyboard doesn't connect successfully within 3 minutes it will enter standby mode.

Specifications

- Keyboard Key Type: Multi Connection Low Profile Keyboard.
- Material: ABS
- Key mechanism: Scissor switch
- Connection interfaces: 2.4G+BT1+BT2+USB
- Type of keycaps: Low Profile / SilkScreen
- Material of keycaps: ABS
- Number of keys: 109 Keys
- Number of multimedia keys: 13 keys

- Battery: 300mAh
- Battery Operating time: 6 Months after full charge
- Cable for charging the device: Yes, cable provides charging and USB wired Connectivity
- Power cord length: 1.5 Meter
- Moisture protection: Yes
- Keyboard size: 16.61*4.6*0.45in
- Weight Keyboard: 1.26 ± .01lbs
- Compatibility: MAC/Windows

Pair the keyboard to device (Quickview)

2.4G	Click/Short press: Switch to 2.4 G channel, insert the USB receiver into the device. Once the LED light stops flashing, it is ready for use.
BT 1	Short Press (1s) Switch the channel to BT1 Mode, Long Press (3s) BT C1 on. The LED BT1 will flash White 1 time /s. Next find Bluetooth name: KB-X231-1 on your host device, Select Connect. After pairing complete the LED turns off.
BT 2	Short Press (1s) to Switch the channel to BT2 Mode, Long Press (3s) BT C2 on. The LED BT2 will flash White 1 time /s. Next find Bluetooth name: KB-X231-2 on your host device. Select Connect. After pairing completes the LED turns off.
mac win	Two-position toggle switch: Up for MAC systems, down for Windows systems
OFF ⊙ ON	Two-position toggle switch: Left side for power off (OFF), Right side for power on (ON)

Note1: Mac systems default to function keys, while Windows systems default to F1-F12 keys.
Note2: Product ships pre-paired with dongle. Instructions are for dongle replacement if lost.

Description of indicator light

Indicator	Color	function	Description
○ ⚡ LED A	Red	Charging & Wired	**Press USB Button:** Switch to wired channel; After connecting the cable, the red light flashes for 3 seconds to indicate a successful wired connection.
○ 2.4G LED C1	Blue	2.4G	**Press 2.4G Button:** Switch to 2.4G channel (On 2.4G channel: Single click has no function / Long press has no function).
○ ✴1 LED C2	Blue	Bluetooth 1:	**Press BT1 Button:** Switch to Bluetooth Channel 1 (On Bluetooth Channel 1: Single click - No function / Long press 3s - Enter Bluetooth 1 pairing mode).
○ ✴2 LED C3	Blue	Bluetooth 2:	**Press BT2 Button:** Switch to Bluetooth Channel 1 (On Bluetooth Channel 1: Single click - No function / Long press 3s - Enter Bluetooth 1 pairing mode).
Caps lock	Green	Caps lock indication	**CAPSLOCK Indicator light:** Green light stays on when Caps Lock is enabled; otherwise, it turns off.
Num Lock	Green	NUM lock indication	**NUM indicator light:** Remains lit green when the numeric keypad is in use; otherwise, it turns off.

HOW TO PAIR (STEP-BY-STEP)

MOVE SLIDER SWITCH ON THE SIDE OF KEYBOARD TO MAC OR PC MODE.

2.4 Ghz Wireless Re-Connection Steps (For Dongle Replacement)

- Power on the keyboard
- Long Press (3s) 2.4G Button: Switches to 2.4G channel and pairing mode. Fast Blue flashing during pairing mode.
- Insert the USB dongle into the host device.
- Once the LED light stops flashing. It is ready for use.

Bluetooth Wireless Connection Steps

Channel 1

- Single click/Short Press BT1 key (1s): Switch to Bluetooth Channel 1 on Bluetooth Channel 1: Long press BT1 Key (3s) - Enters Bluetooth 1 pairing mode. The LED BT CH1 will blink White and flash 1 time /s in pairing mode.
- Select Add Bluetooth Device on your host computer.
- Select Bluetooth KB on your host computer: KB-X231-1, and select Connect. After pairing completes the LED goes off.

Channel 2

- Single click/Short press BT2 key (1s): Switch to BLuetooth Channel 2 on Bluetooth Channel 2: Long press BT2 Key (3s) - Enters Bluetooth 1 pairing mode. The LED BT CH2 will blink White and flash 1 time /s in pairing mode.
- Select Add Bluetooth Device on your host computer.
- Select Bluetooth KB on your host computer: KB-X231-2, and select Connect. After pairing completes the LED goes off.

USB Wired

- Plugin USB Cable to Keyboard and connect to host computer
- Click/Long press USB Key: Switch to wired channel; After connecting the cable, the Red light flashes for 3 seconds to indicate a successful wired connection.

Note:

Once paired or connected via USB you may switch to other modes by a Short Press (1s) "Channel Selection". All previous pairings are retained unless you re-pair 2.4Ghz or Bluetooth Devices using the pairing steps above.

NOTE

- Technical specifications given in this table are supplemental information and cannot give occasion to claims.

- Technical specifications are subject to change without notice due to improvement of Goldtouch production.

- Technical support by Goldtouch Support.

GENERAL

- This product conforms to the US and EU requirements.

- This device complies with part 15 of the FCC rules. Operation in subject to the following two conditions:
    1. This device may not cause harmful interference.
    2. This device must accept interference received, including interference that may cause undersired operation.

- The product is made in accordance with RoHS standards. The product is made on accordance with CE standards. The standards were issued in order to decrease the amount of electronic and electrical waste emitted into the atmosphere.

- The WEEE symbol (the crossed-out wheeled bin) indicates that this product is not home waste. Please protect the environment by recycling appropriately. In order to get detailed information about recycling this product, please contact your retalier or local authority.

CERTIFICATIONS

WARRANTY

There is a one year manufacturer's warranty from date of original purchase date. Customer must submit an RMA form and obtain an RMA number before shipping product back. If product tests non-defective, is damaged, or submitted due to human error then customer is responsible for all shipping costs for return to Goldtouch and back.

After 30 days, customer is responsible for shipping costs to have items sent back for testing.

If defective, Goldtouch will return, at our cost, a replacement factory refurbished product. Warranty for the replacement item continues from the original date of purchase.

The one year warranty does not cover Abuse or Normal wear.

Register your product online:

https://www.goldtouch.com/support/warranty-registration/

Important: Be sure to retain your proof of purchase and for non-European purchasers we recommend registering your Goldtouch Keyboard as it may be required for warranty service.

Information in this document is subject to change without notice. No part of this document may be reproduced or transmitted in any form or by any means, electronically or mechanical, for the purpose, without the express written permission of Key Ovation, LLC. All trademarks are the property of their respective owners.

Goldtouch

Goldtouch

TECHNICAL SUPPORT
HAVING TECHNICAL PROBLEMS
WITH THIS PRODUCT?
Send an email to support@goldtouch.com
for more information, please visit
www.goldtouch.com